

ALL NEW Adhesive Technology!

Save time on vertical applications!

- ▶ Holds strong in less than 5 seconds
- ▶ Strong, permanent bond

Applications

- ▶ Natural Stone
- ▶ Manufactured Stone
- ▶ Indoor/Outdoor
- ▶ Brick, Block & Pavers
- ▶ Glass & Ceramic Tile
- ▶ Veneers
- ▶ Dry Stack
- ▶ Masonry
- ▶ Outdoor Kitchens
- ▶ Metal & Wood
- ▶ Household Repairs



VOC compliant



Ask for it by Name!

Distributed by:

| SRWproducts.com | 800-752-9326 |



SRW PRODUCTS ADHESIVE

Holds strong
in under **5 seconds!**



Vertical Applications



Veneer & Fireplaces



Dry Stack & Outdoor Kitchens



Tile, Glass & Repairs

Vertical Instant Lock

LOOK INSIDE!

Application
Tips & Tricks

WE MAKE IT EASY!

Applying

Cut



Attach



Apply (v-notch up at 90°)



Use the Correct Pattern:

Apply in a continuous bead staying 1/2" (1.27cm) from outer edge. Use an upward arching line to avoid trapped moisture & separate beads by 1 1/2" (3.81cm).

YES: ✓ Recommended.



NO: ✗ Not Recommended.



Great Coverage
≈ 210
linear inches in
a 9.5 oz. tube of
Instant Lock.
(533.4 linear cm)

Use the Best Gun:

SRW's Premium Caulking Gun is recommended for use with Vertical Instant Lock Adhesive.



Online Resources

For videos, Spanish instructions, Safety Data Sheet (SDS), special instructions and more, visit bitly.com/instantlock.



DIRECTIONS:

1. Clear the surface of all materials that may prevent adequate adhesion such as heavy textures, dirt, dust or other loose particles. Surfaces must be flat, completely dry and above 40°F (5°C).
2. To open, cut nozzle base on tube, screw on the v-notch applicator tip.
3. Apply using SRW Premium Caulking Gun. Minimum 14:1 thrust ratio required. At a 90° angle, v-notch up, apply to one of the surfaces in a continuous bead spanning the full width but staying 1/2" (1.27cm) from the outside edge. Additional beads may be needed. Separate beads by 1 1/2" (3.81cm). Do not apply in a dot pattern.
4. Press surfaces firmly together with a slight twisting motion and hold firmly for 5 seconds.

USER TIPS:

- Apply horizontally in an arch pattern to avoid issues from trapped moisture.
- When adhering heavy materials, permanent additional support may be required.
- Be sure the substrate can support the weight. To calculate the recommended amount of linear inches (cm) of adhesive needed, multiply the weight in lbs. (kg) by 2.33 (13.05).
- Not intended for: Suspended or overhead applications; direct contact with flames or fire brick; plastic, rubber or asphalt; around pools and chlorides or for submersion or use below the waterline.

APPLICATION TEMPS: For ease of extraction, working temperature should be between 60-90°F (16-33°C). Above 90°F (33°C), use additional supports for 24 hours.

WORKING TIME: 10 minutes, full cure in 24 hours.

SHELF LIFE: 12 months.

STORAGE: Store in a cool, dry place out of direct sunlight. Will not freeze or be damaged by low temps. Avoid storage temperatures above 120°F (48°C).

CLEANUP: Clean uncured adhesive with mineral spirits.

DISPOSAL: Dispose contents and container in accordance with local, regional, national, and international regulations.

FIRST AID: If exposed or concerned, get medical attention. See SDS, available at www.SRWproducts.com.

Vertical Instant Lock



Instrucciones en español

